

Macbook Pro	model
Macbook Pro 15-inch Touch (2018 / 2019)	A1990
Macbook Pro 13-inch Touch (2018 / 2019)	A1989
Macbook Pro 13-inch Touch (medio 2017)	A1708
Macbook Pro 15-inch Touch (eind 2016 medio 2017)	A1707
Macbook Pro 13-inch Touch (eind 2016)	A1706
Macbook Pro 15-inch Retina (begin 2013 t/m medio 2015)	A1398
Macbook Pro 13-inch (eind 2013 t/m begin 2015)	A1502
Macbook Pro 13-inch (eind 2012/begin 2013)	A1425
Macbook Pro 15-inch Retina (2012)	A1398
Macbook Pro 15-inch (medio 2009 t/m medio 2012)	A1286
Macbook Pro 13-inch (medio 2009 t/m medio 2012)	A1278
Macbook Pro 17-inch (medio 2009 t/m eind 2011)	A1297
Macbook Pro 17-inch (2008)	A1261
Macbook Pro 15-inch (2008)	A1260
Macbook Pro 17-inch (2007)	A1229
Macbook Pro 15-inch (2007)	A1226
Macbook Pro 17-inch (2006)	A1212
Macbook Pro 15-inch (begin 2006)	A1211
Macbook Pro 17-inch (begin 2006)	A1151
Macbook Pro 15-inch (begin 2006)	A1150

Macbook Air	model
Macbook Air 13-inch (eind 2018)	A1932
Macbook Air 13-inch (2017 t/m medio 2012)	A1466
Macbook Air 11-inch (medio 2012 t/m begin 2015)	A1465
Macbook Air 13-inch (eind 2010 / medio 2011)	A1369
Macbook Air 11-inch (eind 2010 / medio 2011)	A1370
Macbook Air 13-inch (eind 2008 / medio 2009)	A1304
Macbook Air 13-inch (2008)	A1237

Macbook	model
Macbook 12-inch (begin 2015 / mid 2017)	A1534
Macbook 13-inch (mid 2010 / Unibody eind 2009)	A1342
Macbook 13-inch (2006 t/m mid 2009)	A1181

1. Kijk achterkant van je MacBook



2. Klik linksboven op het Apple logo en kies "over deze Mac"

